


MAX800 MAX801/MAX802/MAX805/MAX810/MAX815 User Manual



Read entire instruction guide before starting installation.

System Overview


The phone security solution of MAX is well designed based on classical standalone display solutions. It adopts the most advanced technology and has reliable standard security. All its highlights create a wonderful consumer experience, increase sales and prevent theft.

Status

- 1. System will be activate when connect to power source.
- 2. Turn off system: remove power supply and merchandise, disarm alarm by remote.
- 3. LED indicator: "Blue" is "on-guard", "Red" is "alarming"

System Components


- 1. Stand with Power Cord
- 2. Charging Cable
- 3. Remote Control (optional)
- 4. Adapter (5.5V, 2A)



INSTALLATION STEPS




Drill a 20mm diameter hole in display counter (optional) and wipe it clean.




Plug micro-USB connector of charging cable into alarming base port, tighten screws.

INSTALLATION STEPS




Remove clear film off 3M adhesive on alarming




Slide power cable through display counter (optional). Press the security stand firmly for at least 10 seconds.

INSTALLATION STEPS



Plug adapter into power cable and outlet.



(Optional) Tighten wingnuts below counter.

INSTALLATION STEPS



Plug the other connector of charging and alarming cable into merchandise and remove the clear film off silicone rubber. Installation finished.



(Optional)Plug the gap of 3M adhesive remover into security base / bracket holder and turn 90° to remove 3M adhesive.

